



Radio Replacement with Steering Wheel Control Retention for Select Amplified 2017 - Up Subaru Vehicles

#### **PRODUCT FEATURES:**

- Retains select factory features in select Subaru vehicles while functioning with an aftermarket radio.
- Pre-programmed to retain factory Steering Wheel Controls.
- Retains StarLink functionality.
- Retains factory Auxiliary Input.
- Retains factory backup camera (see note on diagram below).
- Includes antenna adapter.
- Retains Harman Kardon amplifier

#### **PARTS INCLUDED:**










SWRSU-38D Module

SU-38D Harness

Antenna Adapter

SWC Cable

#### **INSTALLATION DIAGRAM:**



1 of 2

rev.230201



# SWRSU-38D

Radio Replacement with Steering Wheel Control Retention for Select Amplified 2017 - Up Subaru Vehicles

#### STARLINK RETENTION:

To retain Starlink, separate the Starlink module from the radio and reconnect the harness and antenna connectors to the module. Stuff the Starlink module back into the dash and secure it with zip ties or tape to prevent it from rattling.

<u>NOTE:</u> The front speaker audio will be lost if the StarLink module is removed from the system.



#### **DIP SWITCH SETTINGS:**

## **AFTERMARKET RADIO DIP SWITCH SETTINGS:**

RADIO BRAND:	DIP:	1	2	3	4
Atoto, Dual, Farenheit, Jensen, Pioneer		OFF	OFF	ON	ON
Power Acoustik, Soundstream		OFF	OFF	ON	ON
Blaupunkt, Most off-brand Radios		OFF	OFF	ON	ON
Alpine		OFF	OFF	OFF	OFF
Clarion		OFF	ON	ON	OFF
Kenwood		OFF	ON	ON	ON
JVC		OFF	ON	OFF	ON
Boss, Old Sony		OFF	ON	OFF	OFF
New Sony		OFF	OFF	ON	OFF



**NOTE:** For Atoto, Blaupunkt, Dual, Farenheit, Power Acoustik, Soundstream, and most off-brand radios, check the aftermarket radio's manual to see if the SWC buttons need to be programmed.

#### SUBARU STEERING WHEEL CONTROL DIP SWITCH SETTING:

Subaru	DIP		6	7	8
#1		ON	OFF	OFF	ON
#2		OFF	ON	OFF	ON



### 3.5MM SWC CABLE

Plug in the 3.5MM to 4-Pin SWC cable to the SWC module and the 3.5mm plug to the aftermarket radio SWC port. NOTE: Insulate the Blue/Yellow wire or 3.5mm plug if not being used.

For aftermarket radios that have wires for SWC connections, cut off the 3.5mm plug on the Crux SWC Cable and connect the SWC wires as follows:

Note that there are some radios that only have SWC1 and SWC2, in this case "shield" does not need to be connected.



#### **VEHICLE APPLICATIONS:**

<b>SUBARU</b>	<b>NOTE:</b> = Phone pick up and hang up buttons will be reversed.
2019 - 2022	Ascent w/ Harman Kardon Amplifier
2018 - 2022	Crosstrek w/ Harman Kardon Amplifier
2017 - 2022	Impreza w/ Harman Kardon Amplifier
2018 - 2022	Legacy w/ Harman Kardon Amplifier
2018 - 2022	Outback w/ Harman Kardon Amplifier
2018 - 2021	WRX / STi w/ Harman Kardon Amplifier