# **CROSLEY** COIL RANGE

CREW3552RW/B

## BAKE ASSIST TEMPS

Bake Assist Temps offer preset temperature settings to make cooking even more convenient. Just select a temperature, press start and let the oven do the rest

### UPSWEPT COOKTOP

Go ahead, spill the beans. The upswept Cooktop comes with raised edges to make cleanup a cinch.

## VERSATILE COOKTOP

Our multiple element options provide up to 2,400 watts on the largest burner to help you cook more of your favorites at the same time on the large burners

# GROSLEN

## **INDICATOR LIGHTS**

Check your oven's status and settings at a glance with the Indicator Lights.

## EASY TOUCH ELECTRONIC CONTROLS PLUS

It's smooth sailing on casserole night when you can set bake or broil temperatures with our Easy Touch Electronic Controls

# SELF CLEAN OPTION

No need to scrape and scrub with the Self-Clean Option. Use this setting to let your range do the dirty work for you in just two to four hours.

# LARGE OVEN CAPACITY (4.8 CU. FT.)

Large Oven Capacity gives you the space you need to make dinner and dessert at the same time.