
Kit Layout




Vehicle Feature Checklist

Vehicle Settings	Heated / Cooled Seats
Factory Amplifier	Front Camera
Dual Zone Climate Controls	Blind Spot Cameras
Heated Steering Wheel	Rear Park Sensors

^{*}Additional features may be available depending on your vehicle.




Operating the Display



^{*}Available Camera Icons and Climate Control screen layout will vary based on number of cameras installed / configuration, and available vehicle features.








From the Camera Control screen, touch the Icon for the camera you wish to activate. When finished viewing the image, touch the Icon for the activated camera again to turn off the image.


*Radio must be capable of supporting a camera input and the camera / cameras must be connected to the RPK4-CH4103.


RPK4-CH4103

User Manual

Accessing Common Settings







Accessing Common Settings

Hard Buttons

The four hard buttons located below the RPK4-CH4103 display, give you the ability to assign a single preset to each button to control a specific Climate Control function, force activate a specific camera to display on the radio, or to control select screen settings. Once the buttons have been assigned a function, a descriptive tag above each button showing what function that button performs will be present (this function can be toggled on / off).



If popups are turned on in the menu: The proximity sensor, within the dash bezel, will display the descriptive tabs when your hand is near the buttons. When your hand is removed, the tabs will disappear.

Options that are able to be preset to the hard buttons include:

Climate Control Functions*

- Max A/C
- Svnc
- · Heated Wheel
- · Fan Mode

Camera Functions**

- Camera 1
- Camera 4
- Camera 2
- · Camera 5
- Camera 3

Screen Shortcut Functions*

- Climate
- Camera
- Gauges
- · Display On / Off
- Climate Control Functions will vary for Single Zone and Dual Zone applications.
- ** The number of available cameras will vary based on how many cameras are installed and activated. Additional Hard Button options coming soon!

Assigning function to the Hard Buttons

Step 1

Press the Button Settings icon in the settings menu.



Step 3

Click on the device (Unassigned, Climate Controls, Cameras) operation you wish to program. In the example, we want to use the first hard button to force activate the cargo camera, so we select the Camera option.



Step 2

Touch the tab that corresponds to the hard button that you wish to assign a function to.



Step 4

In the example, because Camera 5 is the cargo camera, we select the Camera 5 option. Repeat steps 3 through 4 for each hard button you wish to program.



