

TE-TATGCHD (CCD) TE-TATGC (CMOS) Toyota Tacoma (2005-2014) Replacement Tailgate Handle with camera

Removal and Installation Instructions

Tools Needed: T30 torx bit, 10mm wrench or socket, ratchet

- I. Start by lowering the tailgate and remove the (15) T30 torx head screws from the tailgate access panel.
- II. Once inner tailgate access panel is removed you will see rods connected to the tailgate handle, disconnect those rods from the tailgate handle by releasing them from the plastic retainers.
 - III. Now remove the (2) 10mm bolts securing the tailgate handle to the tailgate and carefully remove the tailgate handle.
- IV. You will have to swap the locking mechanism out of the old handle to the new one.
 - V. Route the backup camera's wires through the tailgate handle's opening and through the tailgate itself.

NOTE: Avoid areas that might pinch the harness.

- VI. Remove taillight and splice the red power wire from the camera's harness into the reverse light's 12v positive wire. This will trigger the camera to turn on when vehicle is placed in reverse. Attach the black ground wire to a metal non-painted surface.
- VII. Wires can now be fully routed from the tailgate to the cab of the truck and to a video source. The Yellow RCA will plug into the input of your video source; the Red wire goes to the rear camera input trigger wire on your video source.

NOTE: Test to make sure video is working before securing new handle.

NOTE: If desired, parking lines can be removed by attaching the green wires together.

- VIII. Carefully replace new tailgate handle in tailgate and secure the handle using the (2) 10mm bolts that were previously removed.
- IX. Once tailgate handle is secured back in tailgate, reattach rods to handle and secure rods to handle using previously removed plastic retainers.
- X. Replace tailgate access panel with the previously removed (15) T30 torx head screws.



1.800.221.0932 www.iBeamUSA.com 460 Walker Street, Holly Hill, FL 32117